



**DEPILADORA FACIAL**  
***FACIAL HAIR REMOVER***

**TH-HW013**

Por favor, lea cuidadosamente este manual antes de usar el tostador por primera vez. Guarde el manual para futuras consultas.

For you safety and continued enjoyment of this product.  
Always read the instruction book carefully before using.

**ES**

Estimado cliente,


Agradecemos la confianza depositada en nuestra marca THULOS®. Nuestro principal empeño es ofrecer artículos excelentes, manteniendo los más estrictos controles de calidad y cumpliendo todas las normativas vigentes de seguridad.

## **ADVERTENCIAS**

- Mantener fuera del alcance de los niños.
- No utilizar sobre piel irritada. Suspenda su uso si se produce irritación de la piel.
- Tenga precaución cuando lo use alrededor de los ojos.
- No enjuague el cabezal de corte bajo el agua.
- No sumerja la unidad bajo el agua.
- Almacene en un lugar fresco y seco cuando no esté en uso.
- No conecte la batería de forma inadecuada, no la cargue ni la arroje al fuego. La batería puede explotar o tener fugas.
- Deseche las baterías viejas de acuerdo con todas las regulaciones locales aplicables.

## **INSTALAR / CAMBIAR BATERÍAS**



- Retire la tapa (Imagen 1).
- Tome la sección superior de la unidad con una mano, la mitad inferior con la otra, y sepárela (imagen 2) para mostrar el compartimento de la batería.
- Coloque una batería tipo AA en el compartimiento, asegurándose de que el polo positivo (+) esté orientado correctamente.



- Deslice / vuelva a colocar la carcasa inferior de la unidad en su lugar (Imagen 2).

## COMO USAR

- Retire la tapa (Imagen 1).
- Deslice el interruptor ubicado en el costado de la unidad hacia arriba a la posición "ON" (Imagen 3). La luz se encenderá automáticamente cuando la unidad esté en funcionamiento.
- Presione suavemente la cabeza de la unidad contra su piel. La unidad no debe estar en ángulo. Continúe haciendo pequeños movimientos circulares para eliminar el vello no deseado (Imagen 5).
- NOTA: Es normal que el cabezal se caliente con el uso




## LIMPIEZA (Asegúrese de que la unidad esté apagada)

- Gire el cabezal giratorio de depilación en sentido antihorario y levántelo (imagen 4).
- Después de cada uso, el cabezal con un cepillo (incluido) para retirar los residuos de cabello.




## GÚÍA DE USO RÁPIDO


1. Retire la tapa (Imagen 1).



2. Instale la batería: Sujete la sección superior de la unidad con una mano, la mitad inferior con la otra, y sepárela (imagen 2).



3. Encienda la unidad: simplemente deslice el interruptor dorado hacia arriba (imagen 3).



4. Para eliminar el vello: utilícelo con movimientos circulares (imagen 4).



## CONDICIONES DE GARANTÍA

1. Este aparato está cubierto contra cualquier defecto de fábrica.
2. El aparato se cambiará siempre y cuando esté dentro del plazo de
1. Cambio y se devuelva con todos sus accesorios y embalaje.
2. La garantía será válida siempre y cuando el aparato vaya acompañado
3. De su factura o ticket de compra donde salga reflejado el aparato, o también su tarjeta de garantía debidamente cumplimentada y sellada.
4. El aparato estará exento de garantía (no cubierto) cuando:

- 4.1. El aparato tenga señales de golpes y/o caídas.
- 4.2. El aparato presente signos de mal uso.
- 4.3. El aparato presente signos de uso excesivo.
- 4.4. El aparato esté manipulado inadecuadamente.
- 4.5. No tenga documento acreditativo (tarjeta, ticket o factura compra).
- 4.6. El aparato no se ha usado según las instrucciones de uso.

#### NOTAS:

- **Bajo ningún concepto se hará cambio directo o abono directo** sin antes revisar el aparato y las causas por las que se ha averiado.
- **Aparato de higiene personal**, lo cual si el aparato no viene totalmente limpio ni se repara ni se toca, se devuelve al usuario tal cual.

#### NORMAS DE PROTECCIÓN DEL MEDIO AMBIENTE



Este aparato no se debe desechar con los residuos domésticos cuando finalice su durabilidad, sino que se debe ofrecer a un centro de reciclaje de aparatos eléctricos y electrónicos domésticos. Este símbolo en el aparato, manual de instrucciones y embalaje le avisa de este aspecto importante. El/los materiales utilizados en este aparato se pueden reciclar. Mediante el reciclaje de electrodomésticos, usted contribuye a fomentar la protección del medioambiente. Consulte a sus autoridades locales para obtener información acerca del punto de recogida.

## **EN**

We appreciate the confidence placed in us when purchasing this THULOS® product. Our main commitment is to offer excellent items, maintaining the strictest quality controls and complying with all current safety regulations, in order to present a perfect and safe product for domestic use.


Read this instruction manual carefully and save it for later reference. If you deliver the device to third parties, also deliver this instruction manual.

### **WARNING**

- Keep out of reach of children.
- Do not use on irritated skin. Discontinue use if skin irritation occurs.
- Exercise caution when using around eyes.
- Do not rinse trimmer head underwater.
- Do not submerge unit underwater.
- Store in a cool dry place when not in use.
- Do not connect battery improperly, charge, or dispose of in fire. Battery may explode or leak.
- Dispose of old batteries according to all applicable local regulations.



### **INSTALLING / CHANGING BATTERY**

- Remove the cap (Image 1).
- Grab the upper section of the unit with one hand, the bottom half with the other, and pull apart (image 2) to reveal the battery chamber.
- Place 1\*AA battery into the compartment, making sure the positive pole (+) is facing the bottom of the unit.
- Slide/snap the unit's bottom casing back into place (Image 2).




## HOW TO USE

- Remove the cap (Image 1).
- Slide the switch located on the side of the unit upward into the "ON" position (Image 3). The light will automatically turn on when the unit is "ON"
- Gently press the head of the unit flat against your skin. The unit should not be on an angle. Proceed making small circular motions to remove unwanted hair (Image 5).
- NOTE: It is normal for the head to become warm with use.




## CLEANING (Be sure unit is off)

- Twist the rotating hair removal head counter-clockwise and lift off (image 4).
- After each use, clean the head by using a brush (included) to wipe away the hair residue.




## QUICK START GUIDE


1. Remove the cap (Image 1).



2. Install battery: Grab the upper section of the unit with one hand, the bottom half with the other, and pull apart (image 2).



3. Turn unit on: Just slide gold switch upward (image 3).



4. To remove hair: Use in a circular motion (image 4).



## WARRANTY CONDITIONS

1. This appliance is covered against any factory defects.
2. The device is changed for a new one as long as it is within the change period and is returned with all accessories and packaging in good condition.
3. The guarantee will be valid as long as the appliance is accompanied by your invoice or purchase ticket where the exact device and model, or your warranty card duly completed and sealed, is reflected.
4. The appliance will be exempt from warranty when:
  - 4.1. The appliance has signs of knocks and / or falls.
  - 4.2. The appliance shows signs of misuse.
  - 4.3. The appliance has signs of overuse.
  - 4.4. The appliance is improperly handled.
  - 4.5. No supporting document. (Card, ticket or invoice).
  - 4.6. The appliance has not been used in accordance with the instructions for use.

NOTES:



- **Under no circumstances will direct change or direct payment be made** without first reviewing the device and the causes for which it has failed.
- **Personal hygiene device**, so do not repaired or touched if the device is not completely clean, is returned to the user as is.

## GUIDELINES FOR PROTECTION OF THE ENVIRONMENT



This appliance should not be put in to the domestic garbage at the end of its durability, but must be offered at a central point for there cycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and pack again put your attention to this import an tissue.

The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute important push to the protection of our environment. Ask your local authorities for in formation regarding the point of recollection.



**DEPILADORA FACIAL**  
**FACIAL HAIR REMOVER**

**TH-HW013**



EAN: 8436588771261

[www.thulos.com](http://www.thulos.com)

[thulos@thulos.com](mailto:thulos@thulos.com)

Servicio Técnico / Technical Service:

[sat@grupothulos.com](mailto:sat@grupothulos.com)

